


# Waste Bin



KESSEBÖHMER



**Adjustment Instructions**  
Standard Double Pull-Out  
Waste Bin  
Bottom mounted

